

## INTRODUCTION

The PlugLoad PL07 7-outlet Tier 1 Advanced PowerStrip (APS) is an energy-saving surge protector that reduces standby power wasted by TV and PC peripheral electronics. In addition to saving energy, the APS provides surge protection to safeguard electronics against damaging power surges.

## INSTALLATION REQUIREMENT



### POWER CONNECTION

The APS features a heavy-duty power cord with an angled, space-saving plug. It must only be plugged into a grounded receptacle for surge protection to operate correctly. All connected devices should be plugged directly into the APS. Use of an extension cord, adapter or other power strip in conjunction with the APS will void all warranties.

The APS may not be used with an aquarium, humidifier, or any device which may cause condensation or moisture to enter the APS.


The APS must only be used indoors in a cool, dry location. The APS should not be located directly next to a baseboard heater where it is likely to overheat.

Any high-current devices which manufacturers require to be plugged directly into a receptacle must not be plugged into the APS.

The total amperage of devices plugged into the APS must not exceed 15A.


In addition to conditions mentioned above, installation of the APS must comply with UL installation requirements for Relocatable Power Taps and the National Electric Code.

## GETTING TO KNOW THE APS




### SURGE LED INDICATOR

When illuminated green, this LED indicates that the surge protection is functioning normally. If this LED extinguishes at any time, the APS was sacrificed to protect your devices and must be replaced.




### CONTROL OUTLET

This current-sensing outlet controls whether power is supplied to the switched outlets or not. The control device (e.g., TV or PC) must be plugged into this outlet.




### RESETTABLE CIRCUIT BREAKER

The resettable circuit breaker provides protection for all outlets on the APS. If no devices are powered or LEDs lit, press the circuit breaker to reactivate power.




### ENERGY SAVING OUTLETS

The Energy Saving outlets will automatically switch off when the control device (e.g. TV or PC) powers off or enters a standby state.



### ALWAYS-ON OUTLETS

The always-on outlets receive constant power and remain on all of the time.



## APS WARRANTY


The APS warranty is 3 years.

PlugLoad warrants to the original purchaser that for the APS Warranty it shall be free of defects in design, assembly, material, or workmanship and will repair or replace, at its option, any defective APS free of charge.

## HOW IT WORKS


The PlugLoad PL07 7-outlet Tier 1 Advanced PowerStrip (APS) reduces wasteful standby power by turning the peripheral electronics on or off based on the status of the control device. When you power off the control device (e.g., TV or PC), the peripheral electronics (e.g., DVD player or printer) turn off, thereby eliminating standby power waste. Easy to install, the APS is suitable for both residential and commercial applications.

## TV SETUP




**Step 1**

Plug in devices that require constant power (e.g., set-top box) into the outlets labeled "Always On."




**Step 2**

Plug the TV into the outlet labeled "Control."



**Step 3**


Plug in TV peripheral electronics (e.g., AV receiver, DVD player, etc.) into the outlets labeled "Energy Saving."



**Step 4**


Plug the powerstrip into a grounded wall receptacle.

## PC SETUP




**Step 1**

Plug in devices that require constant power (e.g., modem, router, etc.) into the outlets labeled "Always On."




**Step 2**

Plug the CPU into the outlet labeled "Control."



**Step 3**

Plug in PC peripheral electronics (e.g., printer, monitor, speakers, etc.) into the outlets labeled "Energy Saving."



**Step 4**

Plug the powerstrip into a grounded wall receptacle.

## CONNECTED DEVICE WARRANTY

PlugLoad will repair or replace, at its option, any devices which are damaged by a transient voltage surge/spike or lightning strike (an "Occurrence") while properly connected through the APS to a properly-wired AC power line with protective grounding provided that the unit has been registered online for warranty with PlugLoad.

## ENSURE YOU HAVE REGISTERED YOUR APS FOR WARRANTY BY COMPLETING AND SUBMITTING YOUR WARRANTY REGISTRATION FORM AT [WWW.PUGLOAD.COM/WARRANTY](http://WWW.PUGLOAD.COM/WARRANTY)

This Connected Device Warranty is a limited warranty, subject to the limitations and exclusions set forth herein. PlugLoad will spend to repair or replace the damaged connected equipment, at PlugLoad's option, an amount equal to the fair market value of the damaged equipment or the original purchase price of the equipment, whichever is less, up to the maximum amount of \$10,000.

PlugLoad reserves the right to review the damaged APS, the damaged devices, and the site where the damage occurred prior to processing a connected device warranty device claim. All costs of shipping the APS and the damaged devices to PlugLoad for inspection shall be borne solely by the purchaser. PlugLoad reserves the right to negotiate the cost of repairs. If PlugLoad determines, in its sole discretion, that it is impractical to ship the damaged devices to PlugLoad, PlugLoad may designate, in its sole discretion, a repair facility to inspect and estimate the cost to repair such devices. The cost, if any, of shipping the devices to and from such repair facility shall be borne solely by the purchaser.

Damaged APS and connected devices must remain available for inspection until the claim is finalized. The site or location of damage must remain unchanged and available for inspection until inspected by PlugLoad or agents of PlugLoad.

Whenever claims are settled, PlugLoad reserves the right to be subrogated under any existing insurance policies the claimant may have. All above warranties are null and void if the following:

- The APS in use during the Occurrence was not provided to PlugLoad for inspection upon PlugLoad's request at the sole expense of the purchaser.
- PlugLoad determines that the APS has not been installed in accordance with the Installation Requirements, or altered in any way.
- PlugLoad determines that the damage did not result from the Occurrence, or that no Occurrence in fact took place, or that the repair or replacement of the damaged devices is covered under a manufacturer's warranty.

- PlugLoad determines that the connected devices were not used under normal operating conditions or in accordance with labels or instructions.
- The APS was not plugged directly into a grounded outlet receptacle.
- The APS was "daisy-chained" together in serial fashion with other power strips, UPS devices, other surge protectors, or extension cords.
- A three-to-two-prong adapter was used.
- The APS was not used indoors.

This APS is not for use with aquariums or other water-related products. Use only indoors and in dry locations. The Connected Device Warranty only protects against damage to properly-connected devices where PlugLoad has determined, in its sole discretion, that the damage resulted from an Occurrence and does not protect against acts of God (other than lightning) such as flood, earthquake, war, vandalism, theft, normal-use wear and tear, erosion, depletion, obsolescence, abuse, damage due to low voltage disturbances (i.e. brownouts or sags), non-authorized program, or device modification or alteration. This is the sole warranty of PlugLoad; there are no other warranties, expressed or, except as required by law, implied, including the implied warranty or condition of quality, merchantability or fitness for a particular purpose, and such implied warranties, if any, are limited in duration to the term of this warranty. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

In no event shall PlugLoad be liable for incidental, special, direct, indirect, consequential or multiple damages such as, but not limited to, lost business or profits arising out of the sale or use of any APS even if advised of the possibility of such damages. This warranty gives you specific legal rights, and you may also have other rights, which may vary from state to state. Some states do not allow the exclusion or limitation of incidental or consequential damage, so the above limitations may not apply to you.

This warranty is valid only for the original purchaser of the APS. All damage claims against the APS must be made within 30 days from the date of the Occurrence and must be accompanied by a receipt for the damaged devices or the warranty is void and the APS must be registered with PlugLoad.

Warranty is valid in the USA and Canada.

## MAKING A WARRANTY CLAIM

Go to [www.plugload.com](http://www.plugload.com) and submit our warranty claim form online.

## COPYRIGHT AND DISCLAIMER

© 2022 PlugLoad Pte Limited. PlugLoad® is a registered trademark of PlugLoad Pte Ltd. Any typographical, clerical or other error or omission in this document or other documents or information issued by PlugLoad shall be subject to correction without any liability on the part of PlugLoad without notice.